

MADE IN THE USA!

Carefully read instructions in their entirety before the install

Professional installation is recommended. Always use proper safety measures during the install of this product. Do not try to install this product without proper tools, recently calibrated torque wrench, correct torque specifications from factory service manual, safety goggles and gloves. The motorcycle must be in a fixed secure position before the install process begins. DO NOT remove both engine studs at the same time. Shogun is not responsible for any part of your motorcycle for any reason.

Replacement Parts List: Left Side Components (as if you were sitting on the bike)QTYPrice eachPart NumbersDescriptions

1 1 1 1	\$20.00 \$20.00 \$20.00 \$3.50 \$.99	99-FS-750-4809-L 99-FS-750-4800-L 428-9041 99-HB-SH10150180 99-HN-LN10150	Black Left Side Puck White Left Side Puck Left Side Spacer Black Anodized Socket Cap 10 X 1.50 X 180 Main Engine Stud Lock Nut 10 x 1.50
------------------	--	---	--

Replacement Parts List: Right Side Components (as if you were sitting on the bike)					
1	\$20.00	99-FS-750-4809-R	Black Right Side Puck		
1	\$20.00	99-FS-750-4800-R	White Right Side Puck		
1	\$20.00	428-9042	Right Side Spacer Black Anodized		
1	\$3.50	99-HB-SH10150180	Socket Cap 10 X 1.50 X 180 Main Engine Stud		
1	\$.99	99-HN-LN10150	Lock Nut 10 x 1.50		

Frame Sliders: Left and right hand frame slider pucks are same size. Right spacer is longer.

Installation Steps:

- 1. Remove right side bolt. Mount right side puck with supplied spacer using (99-HB-SH10150180) Socket Cap 10 X 1.50 X 180 Main Engine Stud and supplied nut, torque down.
- 2. Remove left side bolt. Mount left side puck with supplied spacer using (99-HB-SH10150180) Socket Cap 10 X 1.50 X 180 Main Engine Stud and supplied nut, torque down.

READ CAREFULLY

Shogun cannot guarantee that they will protect your motorcycle from any extent of damage. Shogun frame sliders are really meant to help possibly save the frame from damage in the event of a crash. Because Shogun frame slider products have been successful in saving cases, bodywork, levers and so on in the past, customers just assume sometimes you can put the product on and no damage will happen. The fact is, some crashes result in little or no damage to the motorcycle and some bikes are destroyed. It's kind of like a bumper on a car sometimes it works sometimes it doesn't, it really depends on all the different forces applied during the incident. We've seen bikes crash at 100 mph with little damage and some at 15 mph with major damage.



